

BeastPower Motorsports, Inc.

Installation Instructions



BeastPower Brackets

- Designed to fit: 1996-2003 BMW 5-series (e39), including the M5
- Tools required:
 - o 2 x 13mm wrenches
 - o Grease or aerosol lubricant
- Parts included:
 - o 2 x BeastPower Brackets (both sides are identical)
 - o 2 x Metric socket head screws, Steel grade 12.9, 8mm x 1.25 x 25mm
 - o 2 x Metric flange nuts serrated, Steel grade 10.9, 8mm x 1.25
 - o 2 x Metric flat washers, Steel grade 10.9, 8mm



Thank you for purchasing a BeastPower Motorsports product! Please read these instructions in their entirety before starting the installation. It is very important that you follow these instructions in the order that they are written. Please make sure you have the right tools and skills to perform this installation. If at anytime you have any questions, please don't hesitate to contact us.

STEP 1


- ⇒ Using two 13mm wrenches, unbolt and remove the original rear sway bar brackets from both sides of the sub-frame mounting points. Leave the bushings on the rear sway bar. It is a good idea to lubricate the bushings using a grease or aerosol lubricant.

STEP 2

- ⇒ Disconnect both sides of the rear sway bar from the suspension swing supports. It is very important to disconnect both sides of the rear sway bar before installing the BeastPower Brackets. The BeastPower Brackets fit very tightly onto the sub-frame mounting points. Do not force the BeastPower Brackets into place without disconnecting the rear sway bar.

LEFT SWING SUPPORT & STOCK BRACKET

Also disconnect the right side before installing the new brackets



STEP 3

- ⇒ Center the BeastPower Brackets in front of the sub-frame mounting points. Slide the BeastPower Brackets partially onto the bushings with the upper lip being inserted into the upper slot on the sub-frame mounting points. Once the upper lip has been inserted, rotate the BeastPower Brackets down onto the bushings, and then secure both BeastPower Brackets to the sub-frame mounting points with the supplied nuts, bolts and washers. The washer should be used on the side with the nut.

STEP 4

- ⇒ Reconnect both sides of the rear sway bar to the suspension swing supports. Check that all parts are secured in place.

DISCLAIMER STATEMENT:

BeastPower Motorsports, Inc. holds no responsibility for incorrectly installed products. An incorrectly installed product could have significant consequences including but not limited to: accidents, bodily injury, automobile damage and other unforeseeable acts. BeastPower Motorsports, Inc. assumes no responsibility for your actions when using our products. Things happen, parts are stressed and break. When a performance part is installed it creates greater stress on itself and other parts, so eventually something will break. BeastPower Motorsports, Inc. products are designed to minimize this breakage of parts. BeastPower Motorsports, Inc. will not be held liable for any part of any automobile that this product will be installed on or any persons injured by use of this product. In no event shall BeastPower Motorsports, Inc. be held liable for direct, indirect, incidental, consequential damages arising from use of the product. By installing and/or using this product you accept and agree to the terms of this Disclaimer Statement. If you do not agree to these terms please return this product.

Driving can be extremely hazardous, and injury or death can occur. No warranty is made or implied regarding any product sold by BeastPower Motorsports, Inc. to protect users from injury or death. The customer, purchaser and/or user assume all risks. BeastPower Motorsports, Inc. is not responsible for typographical or photographic errors. Some of the products sold by BeastPower Motorsports, Inc. may be illegal for use on public roads, please check local laws. The use of the term "BMW" is for reference only, and does not imply any connection between BeastPower Motorsports, Inc. and BMW A.G. Munich or BMW North America or any of their affiliates.